


QUICK START GUIDE


ski~mojo

A


LEFT




RIGHT



B




C



D




E



F





1


LEFT



+



+



GOLD			
	Kg	Lb	
	123	271	24
	121	266	23
	119	262	22
	117	257	21
	115	253	20
	113	249	19
	111	244	18
	109	240	17
	107	235	16
	105	231	15
	103	227	14
	101	222	13
	99	218	12
	97	213	11
	95	209	10
	93	205	9
	91	200	8
	89	196	7
	87	191	6
	85	188	5
	84	185	4
	83	182	4
	82	180	3
	81	178	3
	80	177	2
	79	174	2
	77	170	1
	76	168	0

SILVER			
	Kg	Lb	
	87	191	24
	85	188	23
	84	185	22
	83	182	21
	82	180	20
	81	178	19
	80	177	19
	79	174	18
	77	170	17
	76	168	16
	75	165	15
	73	162	14
	72	159	13
	71	156	12
	69	153	11
	68	150	10
	67	147	9
	65	144	8
	64	141	7
	63	138	6
	61	135	5
	60	133	4
	59	130	3
	57	127	2
	56	124	1
	55	121	0




BLUE			
	Kg	Lb	
	62	136	24
	61	135	23
	60	133	22
	59	130	21
	58	128	20
	57	127	19
	56	124	18
	55	121	17
	54	118	16
	53	117	15
	52	115	14
	51	112	13
	50	109	12
	49	108	11
	48	106	10
	47	103	9
	46	101	8
	46	101	7
	44	98	6
	43	95	5
	42	92	4
	41	89	3
	40	88	2
	39	86	1
	38	83	0

2

RIGHT




+



1

3




+



+




2 cm











LEFT

2 cm




RIGHT

4



5


LEFT + RIGHT




6




7






8





9







10

















13



14







ski~mojo

www.ski-mojo.ski/help